

BASKET CLEANING INSTRUCTIONS

Because fruits and vegetables contain natural substances that will build up and stain the juicer basket, it is important that you follow this set of cleaning instructions. Failure to do so will cause excessive vibration of the machine and may cause bearing and, or motor damage.

- 1) In a pot large enough to cover the basket completely, add 3/4 to 1 cup of **CASCADE COMPLETE LIQUID** dishwashing detergent **PER GALLON OF HOT WATER.**
- 2) Remove the basket from the juicer and rinse under a stream of water to remove as much of the pulp as possible. Place the basket in the cleaning solution and let soak overnight, every night.
- 3) In the morning wash the basket inside and outside with a soft sponge to remove any remaining stains. A soft bristle brush may be used for stubborn spots. **DO NOT USE BLEACH.**
- 4) This soapy solution can be saved and used for 2-3 months.